Chapter 3

Unicast IP

A unicast address is an address that identifies a unique node on a network. Unicast addressing is available in IPv4 and IPv6 and typically refers to a single sender or a single receiver, although it can be used in both sending and receiving.

A unicast address packet is transferred to a network node, which includes an interface address. The unicast address is then inserted into the destination's packet header, which is sent to the network device destination.


Unicast is the most common form of IP addressing.

A unicast address identifies a network device, such as a workstation or a server. A unicast address on a local area network (LAN) contains a subnet prefix and an interface ID.

Multicast IP and Multicast Streaming

A multicast is similar to a broadcast in the sense that its target is a number of machines on a network, but not all. Where a broadcast is directed to all hosts on the network, a multicast is directed to a group of hosts. The hosts can choose whether they wish to participate in the multicast group (often done with the Internet Group Management Protocol), whereas in a broadcast, all hosts are part of the broadcast group whether they like it or not!

- 1) Hardware/Ethernet Multicasting
- 2) IP Multicasting
- 3) Mapping IP Multicast to Ethernet Multicast



HARDWARE/ETHERNET MULTICASTING

When a computer joins a multicast group, it needs to be able to distinguish between normal unicasts (which are packets directed to one computer or one MAC address) and multicasts. With hardware multicasting, the network card is configured, via its drivers, to watch out for particular MAC addresses (in this case, multicast MAC addresses) apart from its own. When

the network card picks up a packet which has a destination MAC that matches any of the multicast MAC addresses, it will pass it to the upper layers for further processing.

To understand this, we need to analyse the destination MAC address of a unicast and multicast packet, so you can see what we are talking about:

When a normal (unicast) packet is put on the network by a computer, it contains the Source and Destination MAC address, found in the 2nd Layer of the OSI model. The following picture is an example of my workstation (192.168.0.6) sending a packet to my network's gateway (192.168.0.5):

No.	MAC source addr	MAC dest. addr	Frame	Protocol	Addr. IP src	Addr. IP dest
1 1	l 00:02:B3:3C:32:68	00:A0:C9:AB:0E:8F	IΡ	TCP->1177	192.168.0.6	192.168.0.5

Now let's analyse the destination MAC address:




a multicast packet is not directed to one host but a number of hosts, so the destination MAC address will not match the unique MAC address of any computer, but the computers which are part of the multicast group will recognise the destination MAC address and accept it for processing.

The following multicast packet was sent from my NetWare server. Notice the destination MAC address (it's a multicast):

No. MAC source addr	MAC dest. addr	Frame	Protocol	Addr. IP src	Addr. IP dest
1 1 00:80:C8:F9:76:EF	01:00:5E:00:00:05	IΡ	OSPFIGP	192.168.0.2	224.0.0.5

Analysis of a multicast destination MAC address:



Broadcast IP

Broadcast is the term used to describe communication where a piece of information is sent from one point to all other points. In this case there is just one sender, but the information is sent to all connected receivers.

Broadcast transmission is supported on most LANs (e.g. Ethernet), and may be used to send the same message to all computers on the LAN (e.g. the address resolution protocol (arp) uses this to send an address resolution query to all computers on a LAN). Network layer protocols (such as IPv4) also support a form of broadcast that allows the same packet to be sent to every system in a logical network (in IPv4 this consists of the IP network ID and an all 1's host number).

Unicast	Broadcast	Multicast		
In unicast, data is delivered from one point to another	In Broadcast, data is delivered from one point to several points	In Multicast, data is delivered from one to (one or more)points		
It has only one sender and one receiver.	It has only one sender but different receiver.	It has one or more sender and there may be zero or more receiver.		
It is single LAN interface means only specific host.	It represents all the devices in LAN means sending to all hosts in a network.	It represents group of devices in LAN means sending to specific hosts.		
If same message is to be delivered to different devices then multiple unicast is required.	In this sender sends specific broadcast address, all those devices who have that broadcast address will process it.	Multicast uses IGMP to identify the groups to which message is to be sent.		
It is one to one technique.	It is one to many technique.	It is one to many.		
Example: Browsing a website.	Broadcasting audio message	ARP request message		


Multicasting versus multiple unicasting

In Multicasting:

- The packet is duplicated by the routers.
- The destination address is between 224.0.0.0 - 239.255.255.255 (class D address) which is the Multicast groups IP addresses.

In Multiple unicasting

- The source sends multiple copies of the same packet, each with a different unicast destination address.
- Example: sending an e-mail to a group



Emulation of multicasting through multiple unicasting is not efficient (use more BW) &may create long delays, particularly with a large group.

TCP/IP Port Numbers

A port is a physical docking point using which an external device can be connected to the computer. It can also be programmatic docking point through which information flows from a program to the computer or over the Internet.

A network port which is provided by the Transport Layer protocols of Internet Protocol suite, such as Transmission Control Protocol (TCP) and User Diagram Protocol (UDP) is a number which serving endpoint communication between two computers.

To determine what protocol incoming traffic should be directed to, different port numbers are used. They allow a single host with a single IP address to run network services. Each port number have a distinct service, and for each host can have 65535 ports per IP address. **Internet Assigned Numbers Authority** (IANA) is responsible for managing the uses of these ports. There are three categories for ports by IANA –

• 0 to 1023 – well known ports or system ports.

Some well-known ports are –

Port number	Transport protocol	Service name
20,21	ТСР	File Transfer Protocol
23	ТСР	Telnet
25	ТСР	Simple Mail Transfer Protocol(SMTP)
53	TCP and UDP	Domain Name System(DNS)
110	ТСР	Post Office Protocol(POP3)
123	UDP	Network Time Protocol(NTP)

- 1024 to 49151 registered ports assigned by IANA to a specific service upon application by a requesting entity.
- **49152 to 65 535** dynamic (private, high) ports range from 49,152 to 65,535. Can be used by private or customer service or temporal purposes.